


Notes:

The BR-Series shapes are designed for heavy-duty service. Due to the fact that all of the webs are thicker and more symmetrical than other shapes, it has more resistance when it comes to the installation.

To install the BR-seal, place one corner of the seal into the joint. Use an in-and-down motion to squeeze the bottom of the seal into the joint opening, then push the seal down to seat in place



NO.	Description	Date	By

The information contained herein is the proprietary property of ERIE METAL SPECIALTIES, INC. No portion of it may be reproduced by any means or used in any form except for the purpose for which it was intended. All rights of design and invention are hereby reserved.



13311 Main Road • Akron • New York • 14001
 Phone: (716) 542-3991 • Fax: (716) 542-3996 • E-mail: sales@eriemetal.com

PROJECT: BR-Series Neoprene Seal
TITLE: Typical Floor-To-Floor Condition

Detailed by: AWG	Date: 07/26/04
Checked by: LJB	Date: 07/26/04
Scale: NTS	EMS Job#:
Sheet No.: 1 of 1	Drawing No.: CD-2600